

SANDING BLOCK

- ❶ Mark your name on the stock given to you beside the number 1
- ❷ Get necessary tools: pencil, ruler, trisquare, marking gauge, jack plane, back saw.
- ❸ Measure and mark stock for cutting: $T = 30$ $W = 60$ $L = 160$
- ❹ Begin by planing the second edge to obtain the correct width.

☞ Be sure not to plane numbered sides
- ❺ Mark and plane second face to obtain correct thickness
- ❻ Mark and saw second end to obtain the correct length
- ❼ Mark and plane top edge and end chamfers