CHOPPING A MORTISE AND TENON JOINT

0	A mortise is a square or rectangular hole cut into a piece of wood into which a tenon,
	cut onto another piece of wood, is fitted.

Select the appropriate hand tools.

Pencil, ruler, tri-square, bench-hook, back saw chisel, hammer, marking gauge.

Mark mortise in the center of one edge of the first piece of stock using the following dimensions:

5mm. wide X 30mm. long X 20mm. deep.

- Mark the tenon on the end of the second piece of stock matching the dimensions of the mortise.
- **6** Chop mortise **first** as instructed.
- **6** Cut tenon as instructed.
 - **be sure** not to cut the tenon too small.
- Trim tenon with a chisel and fit it into the mortise.