<u>DAY 48</u>

LEG SHAPING REVIEW

- The three leg styles for the chess table are; tapered leg, turned leg, and the carved leg.
- The tapered leg is shaped using the the taper leg jig. The jig runs in the slot of the table saw. Tapers are cut on the two inside faces of each leg.
- The turned leg is shaped or turned on the lathe. Calipers are used to check consistency between matching legs. Extra length is left on the ends of legs and cut off when turning is complete.
- The carved leg is shaped using the band saw. Further shaping is done with rasps, files and sandpaper.